



Pro Tech II Assembly Instructions



1. Unlatch seat cushion. Lift and tilt seat cushion forward.



2. Unfold Pro-Tech unit. Extend the cam-wrap strap with the buckle tongue end and 1" strap down into the seat bight between the seat back and the cushion.



3. Return seat cushion to original position and re-latch. Beneath the seat, bring forward and connect the 1" strap to the buckle on the front of the Pro-Tech seat pad (secure the Pro-Tech to the seat cushion). Adjust strap until snug and Pro-Tech pad does not move significantly side to side.



4. Push the Pro-Tech seat pad firmly against the seat back. Buckle the cam-wrap behind the seat with the buckle facing inward. Tighten the cam-wrap until the seat top foam indents slightly. There should not be any slack in the cam-wrap.



5. Adjust torso height to be at or above the occupant's shoulders by sliding the webbing into the correct slot for proper fit. Use the lower slot for shorter children, the middle slot for average sized children, and the upper slot for taller occupants.



6. When using the Pro-Tech II, place child in seat. Connect the color coded straps together. Pull the adjustment straps to fit firmly across the hip and shoulder areas. The webbing should not have any slack (Pinch Test).

Warning! Securement must only be used on school bus seats. Entire seat directly behind must be unoccupied or have secured occupants.

Recommended replacement after 6 years in service.

BESI Pro Tech II Part Numbers:

BESI Pro Tech II Pouch Only.....30-0002-0145

BESI Pro Tech II Securement Only.....30-0003-0145



BESI Contact Information

9087 Sutton Place
West Chester, OH 45011

Phone: 513-874-0232
Toll Free: 800-543-8222

Register your product online at
www.besi-inc.com



For Additional information on our full line of
products scan code!